

QuickPen

PipeDesigner 3D[®]

AutoCAD[®] 2008
AutoCAD[®] Architecture 2008
AutoCAD[®] MEP 2008

Viewer
Installation

QuickPen
SMART • SOLID • SOFTWARE

1998-2008 QuickPen International Incorporated. All rights reserved.

This publication, or parts thereof, may not be reproduced in any form, by any method, for any purpose, without the written consent of QuickPen International Incorporated.

Published by: QuickPen, International, Incorporated
384 Inverness Parkway, Suite 200
Englewood, Colorado 80112
(800) 234-3758

Edition: PipeDesigner 3D® Viewer Download and Installation Instructions
April 24, 2008 Part # PD3D8059.38.0408_Viewer Installation 2008.2

All QuickPen products are trademarks or registered trademarks of QuickPen International Incorporated. Microsoft, Windows and/or other Microsoft products referenced herein are either trademarks or registered trademarks of Microsoft Corporation. Autodesk ® products are copyrighted material solely and exclusively owned by Autodesk Inc. Adobe Reader is a registered trademark of Adobe Systems Incorporated. NavisWorks is a trademark of NavisWorks Ltd. iButton is a trademark of Dallas Semiconductor Corporation. Other brand and product names are trademarks or registered trademarks of their respective holders

Any unauthorized modification, reproduction and/or redistribution of materials in written or electronic forms is expressly prohibited.

PipeDesigner 3D[®]

Release 2008 v2

Viewer Installation Instructions

This document includes instructions for proper installation of the viewer application. QuickPen suggests that you review and follow the instructions to ensure that PipeDesigner 3D Viewer functions properly after installation.

Note: This viewer is compatible only with PipeDesigner 3D, release 2008 v2, and the following Autodesk 2008 product series: AutoCAD[®] 2008, AutoCAD[®] Architecture and AutoCAD[®] MEP. It will not work with previous versions of these applications.

Preliminary Steps

Perform the following procedures before beginning the update installation.

➤ Windows Applications

Make sure all Microsoft Windows® based applications on the server are closed, including e-mail software, and virus protection software.

➤ Uninstall Applications

You must uninstall previous versions of the PipeDesigner 3D Viewer prior to installing the latest application.

Uninstall Previous Version of PipeDesigner 3D Viewer

1. Choose **Start > Settings > Control Panel**.
2. Double-click on **Add or Remove Programs**.
3. Locate **PipeDesigner 3D Viewer** and then click on the **Remove** button.
4. In the InstallShield window, choose the **Remove** radio button. Click **Next**.
5. Choose **OK** to confirm.
6. Click **Finish**.

QuickPen recommends that you restart your computer when the viewer application is removed. Once this is complete, proceed with the PipeDesigner 3D Viewer installation.

Download Procedures

Caution Do *not* install the PipeDesigner 3D Viewer on the same computer where the PipeDesigner application is located. Doing so will cause conflicts within the PipeDesigner 3D program.

- If you are installing from the installation compact disk, proceed to the *Installation Procedures* section.
- If you want to download the PipeDesigner 3D Viewer from the QuickPen website, proceed as follows.
 1. Navigate to the **PipeDesigner 3D Viewers** heading.
 2. Locate the *PipeDesigner 3D 2008 v2 Viewer*. Read the product notes and then complete the following procedures to download the file to your computer.
 3. Click on the **PipeDesigner 3D Viewer.msi** file link.
 4. In the File Download window, choose **Save**.
 5. In the **Save As** window, navigate to the location you want to use for the download, then choose **Save**. Make note of where you saved the file.
 6. When the download is complete, click **Close** the Download window. *Note:* Depending on your computer settings, the Download window may close automatically.

Continue to the *Installation Procedures* section for additional procedures.

Installation Procedures

Caution Do *not* install the PipeDesigner 3D Viewer on the same computer where the PipeDesigner application is located. Doing so will cause conflicts within the PipeDesigner 3D program.

To ensure proper behavior of the application, please follow all of the procedures as outlined in the next topics. Depending on whether you are installing from the compact disk or downloading from QuickPen's website, go to the appropriate instructions below.

Installation Compact Disk

1. Insert the PipeDesigner 3D installation compact disk into the CD drive of the stand-alone computer.
2. Depending on your computer settings, the installation may not start automatically. If it does not start a few seconds after you insert the compact disk,
 - Double-click on the **My Computer** icon.
 - Locate the drive containing the PipeDesigner 3D Installation compact disk.
 - Click on it to display the PipeDesigner 3D installation window.
3. Choose **Explore: CD-ROM**.
4. Navigate to the **Programs** folder and then double click on the **PD3D Viewer** folder.

Downloaded File

Navigate to the location where you saved the downloaded file.

Install Viewer

1. Double-click on **PipeDesigner 3D Viewer** file.

Note: Depending on your computer settings, you may see an *msi* file extension. Also, if you downloaded the file from QuickPen's website, you may receive a security warning message. The message is designed to protect your computer and can be ignored for the viewer installation. Click **Run**.

The installation begins.

2. The Welcome to the PipeDesigner 3D Viewer Setup screen displays. Choose **Next**.
3. The End-User License Agreement displays on the screen. Read the agreement. Choose **I accept the terms of the license agreement** checkbox. **Note:** *You must accept the terms of the agreement to proceed with the installation.* Click **Next**.

4. The **Destination Folder** screen displays. *QuickPen recommends that you install the software in the default location displayed on the screen. Choose **Next**.*
5. The **Ready to install PipeDesigner 3D Viewer** screen displays. Click **Install** to begin the PipeDesigner 3D Viewer installation. A progress indicator displays while the application is installing.
6. When the installation is complete, click **Finish**.
7. Close all remaining open files, if applicable.

When the installation is complete, you can open your Autodesk application and easily view drawings and edit (move, copy, stretch) entities created in PipeDesigner 3D.