

QuickPen
DuctDesigner 3D

AutoCAD® 2008
AutoCAD® Architecture 2008
AutoCAD® MEP 2008

Viewer
Installation

QuickPen
SMART • SOLID • SOFTWARE

1998-2008 QuickPen International Incorporated. All rights reserved.

This publication, or parts thereof, may not be reproduced in any form, by any method, for any purpose, without the written consent of QuickPen International Incorporated.

Published by: QuickPen, International, Incorporated
384 Inverness Parkway, Suite 200
Englewood, Colorado 80112
(800) 234-3758

Edition: DuctDesigner 3D[®] Viewer Installation Instructions, 2008 v3
February 4, 2008 Part # AM8063.30.0208_Viewer Installation Instructions

All QuickPen products are trademarks or registered trademarks of QuickPen International Incorporated. Microsoft Windows and/or other Microsoft products referenced herein are either trademarks or registered trademarks of Microsoft Corporation. AutoCAD[®] and other AutoDesk applications referenced in this document are trademarks or registered trademarks of Autodesk, Inc. NavisWorks is a trademark of NavisWorks Ltd. iButton is a trademark of Dallas Semiconductor Corporation. Other brand and product names are trademarks or registered trademarks of their respective holders.

Any unauthorized modification, reproduction and/or redistribution of materials in written or electronic forms is expressly prohibited.

DuctDesigner 3D[®]

Release 2008 v3

Viewer Installation Instructions

This document includes instructions for proper installation of the viewer application. QuickPen suggests that you review and follow the instructions to ensure that DuctDesigner 3D Viewer functions properly after installation.

Preliminary Steps

Perform the following procedures before beginning the installation.

➤ **Windows Applications**

Make sure all Microsoft Windows® based applications on the server are closed, including e-mail software, and anti-virus protection software.

Download Procedures

- If you are installing from the installation compact disk, go to the *Installation Procedures* section.
 - If you want to download the DuctDesigner 3D Viewer from the QuickPen website, proceed as follows.
1. On the DuctDesigner 3D Downloads page, go to the **Duct Designer 3D Release 2008 v3 Viewer** section. Read the product notes and then complete the following procedures to download the file to your computer.

Caution: Do *not* install the *DuctDesigner 3D Viewer* on the same computer where the DuctDesigner 3D application is located. Doing so will cause conflicts within the DuctDesigner 3D program.

2. Click on **Download Now**. In the File Download window, choose **Save**.
3. In the **Save As** window, navigate to the location you want to use for the download, then choose **Save**. Make note of where you saved the file.
4. When the download is complete, click **Close** the Download window. *Note:* Depending on your computer settings, the Download window may close automatically.

Continue to the *Installation Procedures* section for additional procedures.

Installation Procedures

Caution: Do *not* install the DuctDesigner 3D Viewer on the same computer where the DuctDesigner application is located. Doing so will cause conflicts within the DuctDesigner 3D program.

To ensure proper behavior of the application, please follow all of the procedures as outlined in the next topics. Depending on whether you are installing from the compact disk or downloading from QuickPen's website, go to the appropriate instructions below.

Installation Compact Disk

1. Insert the DuctDesigner 3D Installation compact disk into the CD drive of the stand-alone computer.
2. Depending on your computer settings, the installation may not start automatically. If it does not start a few seconds after you insert the compact disk,
 - Double-click on the **My Computer** icon.
 - Locate the drive containing the DuctDesigner 3D Installation compact disk.
 - Click on it to display the DuctDesigner 3D installation window.
3. Choose **Explore: CD-ROM**.
4. Navigate to the **Viewer** folder and then double click on **DuctDesigner 3D Viewer**.
Note: Depending on your computer settings, you may see a file extension after the file name.

Downloaded File

1. Navigate to the location where you saved the downloaded file.
2. Double-click on **DuctDesigner 3D 2008.2 Viewer** file. *Note:* Depending on your computer settings, you may see a file extension after the file name.

Install Viewer

1. Click on the downloaded file or the file in the **Viewer** folder (on the installation compact disk) to begin the installation. *Note:* If you downloaded the file from QuickPen's website, you may receive a security warning message. The message is designed to protect your computer and can be ignored for the viewer installation.
2. The Welcome to the QuickPen Wizard for DuctDesigner 3D Viewer screen displays. Choose **Next**.
3. The License Agreement displays on-screen. Read the agreement. Choose **I accept the terms in the license agreement** checkbox. Click **Next**.

Note: You must accept the terms of the agreement to proceed with the installation. If you want to print the agreements before proceeding, click on the **Print** button..

4. The Destination Folder screen displays. *QuickPen recommends that you install the software in the default location displayed on the screen.* Choose **Next**.
5. In the Completing the QuickPen Wizard for DuctDesigner 3D Viewer screen, click **Next**.
6. When the installation is complete, click **Finish**.
7. Close all remaining open installation files (if applicable).