

QuickPen
DuctDesigner 3D

AutoCAD® 2009
AutoCAD® Architecture 2009
AutoCAD® MEP 2009

Viewer
Installation

QuickPen
SMART • SOLID • SOFTWARE

1998-2009 QuickPen International Incorporated. All rights reserved.

This publication, or parts thereof, may not be reproduced in any form, by any method, for any purpose, without the written consent of QuickPen International Incorporated.

Published by: QuickPen, International, Incorporated
384 Inverness Parkway, Suite 200
Englewood, Colorado 80112
(800) 234-3758

Edition: DuctDesigner 3D[®] Viewer Installation Instructions, 2009 v2
May 27, 2009 Part # AM8063.30.0509_Viewer Installation Instructions

All QuickPen products are trademarks or registered trademarks of QuickPen International, Incorporated. Microsoft®, Office, Windows and/or other Microsoft products referenced herein are either trademarks or registered trademarks of Microsoft Corporation. Autodesk[®] products are solely and exclusively owned by Autodesk Inc., including but not limited to AutoCAD[®], AutoCAD[®] Architecture, AutoCAD[®] MEP and NavisWorks[®]. Adobe Reader[®] is a registered trademark of Adobe Systems Incorporated. Other brand and product names are trademarks or registered trademarks of their respective holders.

DuctDesigner 3D[®]

Release 2009 v2

Viewer Installation Instructions

This document includes instructions for proper installation of the viewer application. QuickPen suggests that you review and follow the instructions to ensure that DuctDesigner 3D Viewer functions properly after installation.

Preliminary Steps

Perform the following procedures before beginning the installation.

Perform the following procedures before beginning the update installation.

➤ **Verify Autodesk Application**

Before installing this version of the DuctDesigner 3D Viewer, verify that you have a compatible Autodesk application installed.

➤ **Windows Applications**

Make sure all Microsoft Windows® based applications on the server are closed, including e-mail software, and virus protection software.

➤ **Uninstall Applications**

You must uninstall previous versions of the DuctDesigner 3D Viewer prior to installing the latest application.

Uninstall Previous Version of DuctDesigner 3D Viewer

1. Choose **Start > Settings > Control Panel**.
2. Double-click on **Add or Remove Programs**.
3. Locate **DuctDesigner 3D Viewer** and then click on the **Remove** button.
4. In the InstallShield window, choose the **Remove** radio button. Click **Next**.
5. Choose **OK** to confirm.
6. Click **Finish**.

QuickPen recommends that you restart your computer when the viewer application is removed. Once this is complete, proceed with the DuctDesigner 3D Viewer installation.

Download Procedures

- If you are installing from the installation compact disk, go to the *Installation Procedures* section.
 - If you want to download the DuctDesigner 3D Viewer from the QuickPen website, proceed as follows.
1. Go to <http://quickpen.com/ductdesigner-3d-support-center.htm> and then click **Viewers**.
 2. Locate the *DuctDesigner 3D 2009 v2 Viewer*. Read available product notes.

Complete the following procedures to download the file to your computer.

3. Depending on your operating system, click on the appropriate DuctDesigner 3D viewer file:
 - *32-Bit operating systems*, double-click **DuctDesigner 3D Viewer(x86).exe**
 - *64-Bit operating systems*, double-click **DuctDesigner 3D Viewer(x64).exe**.
4. In the File Download window, choose **Save**.
5. In the **Save As** window, navigate to the location you want to use for the download, then choose **Save**. Make note of where you saved the file.
6. When the download is complete, click **Close** the Download window. *Note*: Depending on your computer settings, the Download window may close automatically.

Continue to the *Installation Procedures* section for additional procedures.

Installation Procedures

Caution: Do *not* install the DuctDesigner 3D Viewer on the same computer where the DuctDesigner application is located. Doing so will cause conflicts within the DuctDesigner 3D program.

To ensure proper behavior of the application, please follow all of the procedures as outlined in the next topics. Depending on whether you are installing from the compact disk or downloading from QuickPen's website, go to the appropriate instructions below.

Installation Compact Disk

1. Insert the DuctDesigner 3D Installation compact disk into the CD drive of the stand-alone computer.
2. Depending on your computer settings, the installation may not start automatically. If it does not start a few seconds after you insert the compact disk,
 - Double-click on the **My Computer** icon.
 - Locate the drive containing the DuctDesigner 3D Installation compact disk.
 - Click on it to display the DuctDesigner 3D installation window.
3. Choose **Explore: CD-ROM**.
4. Navigate to the **Viewer** folder and then double click on the appropriate viewer file based on you currently operating system:
 - **32-Bit operating systems**, double-click **DuctDesigner 3D Viewer(x86).exe**
 - **64-Bit operating systems**, double-click **DuctDesigner 3D Viewer(x64).exe**.

Note: Depending on your computer settings, you may see a file extension after the file name.

Downloaded File

1. Navigate to the location where you saved the downloaded file.
2. Double-click on **DuctDesigner 3D Viewer[].exe** file. *Note:* Depending on your operating system and computer settings, your file will display differently than above.

Install Viewer

1. Click on the downloaded file or the file in the **Viewer** folder (on the installation compact disk) to begin the installation. *Note:* If you downloaded the file from QuickPen's website, you may receive a security warning message. The message is designed to protect your computer and can be ignored for the viewer installation.

2. The Welcome to the DuctDesigner 3D Viewer Setup screen displays. Choose **Next**.
3. The End-User License Agreement displays on-screen (*Software License Agreement*). Read the agreement. Choose the **I accept the terms in the License Agreement** checkbox. Click **Next**.
4. The second End-User License Agreement displays on-screen (*Customer Care Agreement*). Read the agreement. Choose the **I accept the terms in the License Agreement** checkbox. Click **Next**.

5.

Note: You must accept the terms of the agreement to proceed with the installation.

6. The Destination Folder screen displays. *QuickPen recommends that you install the software in the default location displayed on the screen.* Choose **Next**.
7. In the Ready to install DuctDesigner 3D Viewer screen, click **Install**.
8. When the installation is complete, click **Finish**.
9. Close all remaining open installation files (if applicable).